



Tips & Tricks

If your Rave doesn't turn on when you press the control buttons, it is likely not charged. Follow these charging instructions:

- 1) Please hold down the on/off button (Figure 1) for 10-15 secs to boot the unit out of any abnormal state.
- 2) Insert the charging pin into the hole (the charging port) above the control buttons on the vibrator (Figure 2).
- 3) Plug the USB cable into a USB port or a USB adaptor and connect to a power source.
- 4) A light between the charging port and the control buttons will illuminate and blink while your Rave is charging; when it is completely charged, the light will illuminate solid.

The Rave charger features an automatic shutoff, so you can always leave it plugged in.

